

INSTALLING BASE TRIM (2, 3 OR 4 WAY)



ASSEMBLY TIME

2 to 5 minutes
(Time of length depends on the installation of the 1, 2 or 3 way compression fits)

TOOLS NEEDED TIME

No tools needed

PARTS

- 2 Way Base Trim**
(Requires one inside)
- or
- 3 Way Base Trim**
(Requires two inside)
- or
- 4 Way Base Trim**
(Requires four inside)



INSTALLATION EXAMPLES

STEP 1 (3 WAY OUTSIDE TRIM)



Place three way bottom trim tabs into metal track and push down until top lip on trim seats into the connector tube.

STEP 2 (3 WAY OUTSIDE TRIM)



Attach base covers to track.

STEP 1 (2 WAY OUTSIDE CORNER TRIM)



Place two bottom trim tabs way bottom trim tabs into metal track and push down until top lip on trim seats into the connector tube

STEP 2 (2 WAY OUTSIDE CORNER TRIM)



Attach base covers to track

STEP 3 (2 WAY INSIDE CORNER TRIM)



Place two inside bottom trim tabs way bottom trim tabs into metal track and push down until top lip on trim seats into the connector tube.

STEP 4 (2 WAY INSIDE CORNER TRIM)



Attach base covers to track.