

OPS-K11 Parts



Step 1:
Assembly Process – Back

- *Place the seat flat.
- *Put the chair back into the hole of mechanism.
- *Align the 3 screws with the holes and put them in.
- *Fasten the 3 screws.



Step 2:
Assembly Process – Arm

*Attach the arms with seat pan and tighten (2) screws.





Step 3:

Attach the casters to the base by firmly pushing in.

Step 4:

Put the cylinder into the base.

Step 5:

Put the upper body into the cylinder.