



Arm-Pad Up & Down Adjustment
Lift up on button located underneath the arm-pad to adjust armrests.



Ratchet Back Height Adjustment
Press button to raise or lower back.



Backrest Tilt Adjustment
Lift up on left paddle to adjust backrest position.



Syncro Tilt Control
Lift up on front right lever to unlock and slide body to adjust backrest and seat.



Seat Slider Adjustment
Lift up on front right paddle under seat to adjust seat slider.



Adjustable Tilt Tension
Twist knob under seat to adjust backrest tension. Twisting clockwise increases tension.



Seat Height Adjustment
Twist paddle on right side to adjust seat height.