



If your remote control needs to be connected or reset for any reason, you will need to follow the process below to pair your new remote control unit.

Step 1. Unplug your Emerge II unit and wait for 60 seconds.

Step 2. Remove the battery cover from the back of your new Remote Control Unit, and remove any plastic covering the battery if present.




EMERGE II

PAIRING REPLACEMENT REMOTE CONTROL

Step 3. Press and hold the button inside the Remote Control Unit behind the battery cover with a pen or paper clip as shown below until the light on the front begins flashing blue.



Step 4. Plug in your Emerge II unit. The blue light on the front of the unit will begin flashing as it searches for your Remote Control Unit.



Step 5. After a few seconds, the blue light should stop flashing and your unit should be paired. If your Remote Control Unit is still not pairing, remove then re-insert the battery and repeat the process, or call customer support.