

INITIAL START UP AND RESET PROCEDURES

Generation 2

Note: You must "reset" the unit prior to use

Note: A Reset procedure requires the desk base to fully retract (beyond any lower limit set). Please ensure that you have the proper clearance below the desk base.

1. Press the UP and DOWN buttons simultaneously for approximately 15 seconds. You should hear an audible beep, continue to hold the UP and DOWN buttons.
2. As you continue to hold the UP and Down buttons, the legs should lower to their lowest possible position until you hear another audible beep.
3. Release the UP and DOWN buttons and your desk unit should be working properly.

2 LEG TABLE (GEN 2)

e-table48-72-3

